

FIG. 4




FIG. 4

FIG. 1










FIG. 2



300

An arrow pointing from the label '300' to the central system block.



224

TO INTERNET

An arrow pointing downwards from the bottom of block 220, with the label '224' to its left and 'TO INTERNET' to its right.

FIG. 3




FIG. 4





Fig. 5A




FIG. 5B




FIG. 6

FIG. 7A

702

700




FIG. 7A

704

706

710




FIG. 7B






FIG. 8




FIG. 9A




FIG. 9B




FIG. 9C




FIG. 10A




FIG. 10B




FIG. 11




FIG. 12






FIG. 13




FIG. 14

Internet Provider

Remote Control Home

Home Security

- ☒ Turn On Home CAM
- ☐ Turn off Home CAM
- ☒ Detect Change in Room

Security Breach In Room:

Bedroom 1 : No  
Bedroom 2 : No  
Living Room : Yes

View Security Breach

More Settings

Home Utilities

Temperature Control

72°F

Room Lighting:

ON OFF  
Bedroom 1 ☐ ☒  
Bedroom 2 ☐ ☒  
Living Room ☒ ☐

WATER GARDEN:

FRONT: ☐ ☒  
Time   
BACK: ☐ ☒  
Time

More Settings

Home Entertainment Controls

Set TV For Recording: ☒ ON ☐ OFF

Select Channel for Recording:

channel  Start Time/Date   
channel  Start Time/Date   
Channel  Start Time/Date

More Settings

FIG. 15

US 2017/0100000 A1




FIG. 16




FIG. 17